

QUICK TECHNOLOGY GUIDE



HOW TO FIND THE MAC ADDRESS XBOX ONE

1. Go to **My Xbox** in the Xbox dashboard and select **Settings**.
2. In the Settings pane, select **Network**.
3. Select **Advanced Settings** from the **Network Settings** tab.
4. At the bottom of this screen, you'll see a heading for **Wired MAC** and **Wireless MAC**.
5. Register both MAC addresses if you are unsure about which one to register.

The screenshot shows the 'Advanced settings' screen on an Xbox One. On the left, there is a sidebar with three options: 'IP settings' (highlighted in green), 'DNS settings', and 'Alternate MAC address'. The main area displays network settings for 'Wireless' and 'IPv4'. Under 'Wireless', the 'Wired MAC' is listed as 28-18-78-28-18-78 and the 'Wireless MAC' is 28-18-28-18-EB-2E. A red box highlights these two MAC addresses. At the bottom, it states 'You're connected using IPv4. Read about using IPv6 at xbox.com/IPv6'.

Advanced settings	
IP settings	Wireless
DNS settings	IPv4
Alternate MAC address	IP address 10.12.20.25
	Subnet mask 255.255.240.0
	Gateway 10.12.16.1
	DNS 10.2.2.2
	Wired MAC 28-18-78-28-18-78
	Wireless MAC 28-18-28-18-EB-2E
	You're connected using IPv4. Read about using IPv6 at xbox.com/IPv6

For all other technical challenges please visit fixit.fau.edu.



wi-fi



gaming console



smart tv



other devices