

QUICK TECHNOLOGY GUIDE



SET UP YOUR TV WITH FAU CABLE

Note: Instructions vary depending on the make and model of the television. This is a general guide. For detail instructions, please refer to your Television user's manual.

Your TV needs to scan for channels before it can show programming from cable TV when the cable comes directly from the wall (no cable box). If you are not using the "TV" input, press the **INPUT** button on your remote until the correct input mode is selected.

To perform a channel scan using the **Coaxial Input**:

1. Press the **INPUT** button on your remote to view your current input source. The TV (Coaxial cable) input must be selected. This may appear as "TV", "ANT", or the channel and call letters of a station.
2. If the TV input is not selected, press **INPUT** until the **TV Input Mode** is selected.
3. Open the **On-screen Menu** and select the **TV or Tuner Option**. (This varies by model)
4. Highlight tuner mode and select the **CABLE (Not Antenna) Option**: Cable - direct from the wall cable TV, or a cable or satellite box connected to the TV with coaxial cable.
5. Select **Auto Search** or **Auto Channel Scan**. (This varies by model) When the search reaches 100% complete, you should have all the channels saved.

For all other technical challenges please visit fau.edu/student/technology



wi-fi



gaming console



smart tv



other devices